

Sanitary Facilities

DESCRIPTION

Facilities for collection and disposal of sanitary waste must be provided and properly managed to minimize the potential contamination of surface water with septic wastes. Location of portable facilities away from storm drain systems and surface waters or containment is necessary in case of spills.

PROCEDURES

- Sanitary facilities must be provided on the site in close proximity to areas where people are working.
- Portable toilets must be provided if no permanent facilities are available.
- Locate portable toilets a minimum of 20 feet away from storm drain inlets, conveyance channels, or surface waters
- If unable to meet 20-foot distance requirement, provide containment for portable toilets.
- Portable toilets should be regularly serviced.

Applications

- Perimeter Control
- Slope Protection
- Sediment Trapping
- Channel Protection
- Temporary Stabilization
- Permanent Stabilization

Waste Management

Housekeeping Practices

Targeted Constituents

- Sediment
- Nutrients Toxic Materials
- Oil & Grease
- Floatable Materials
- Other Construction Wastes

Implementation Requirements

- Capital Costs
- Maintenance
- Training
- Suitability for Slopes > 5%

Legend

- Significant Impact
- Medium Impact
- Low Impact
- ? Unknown or Questionable Impact

M-7



North Central Texas
Council of Governments